

Play/Pause any dynamic color changing pattern.



On/Off



Brighter/Dimmer on Static colors.



Faster/Slower color changes on dynamic modes.

Select static color modes, includes white.

Up and down arrows to increase or decrease saturation of color




Six DIY buttons for entering custom color programming. Press and hold any DIY button to save programmed custom color.



Cycles all patterns randomly (may adjust speed).



On/Off static color strobe mode (may adjust speed).



7 color fade (may adjust speed).

3 color fade (may adjust speed).

7 color change (may adjust speed).

3 color change (may adjust speed).